

125^{cc}



USER MANUAL

BLACK SEVEN



Congratulations !

You are the happy new owner of a MASH which embodies a new spirit, a new trend : a motorcycle with a look and a philosophy «Vintage», synonymous of freedom.

Please read this manual thoroughly before using your MASH.

Have a nice road !

Important Cautions

About running-in of a motorcycle

The first 1000 km operation is very important in the entire service life of a motorcycle. A correct running-in can guarantee both the longest service life and the best performance of the vehicle. Running-in can polish machined surfaces and form smooth engagement.


Careful and patient running-in can make the motorcycle stable in driving and give a full play to its excellent performance. It is important not to do any operation that may cause overheat to engine components.

For specific running-in method, please refer to «Running-in of a new vehicle».

Please carefully read the manual and strictly observe all instructions or descriptions.

Special Caution shall be paid to the contents emphasized with the terms of «warning» «caution» and «note»,

 **Warning : It concerns with personal safety. Ignoring it may result in accident.**

 **Caution : It refers to operational methods that must be followed or measures that should be taken, so as to prevent damage.**

Note : It refers to special explanations to make maintenance or important descriptions more explicit

The operation manual shall be deemed as a permanent document of the motorcycle. When transfer the vehicle to others, the instruction manual shall also be transferred to the new owner

Slight variations can however be observed between the models, composing the range. If this manual mentions details that are different from the actual model, do not consider them.

Black 7 Seven



British 7 Seven



CHASSIS NUMBER

ENGINE NUMBER

DISTRIBUTEUR

Chassis number (or VIN code) and engine number is necessary for registration of your motorcycle. Such numbers are needed with order components or service, to allow the distributor to provide you with better service.

Chassis number (or VIN code) is on the riser pipe of chassis. Engine number is on the left side of crankcase. Metal nameplate is on the riser pipe of chassis, showing the main technical parameters, manufacturer and date of production of the motorcycle.

Write the numbers in the spaces below, for future reference.

Foreword

Confratulations on your choice!

If riding a motorcycle is one of the most exciting hobbies. This vehicle is also an ideal means of transport, which guarantees you unlimited driving pleasure. Before driving, you are encouraged to familiarize yourself with the instructions and specifications in this instruction manual, which describes in particular the rules for using and maintaining the vehicle.

Observing the following recommendations will ensure the reliability of your motorcycle and prolong its life.

The staff of MASH authorized dealers (list available by consulting the website www.mash-motors.fr) have the skills and technical qualifications required to carry out maintenance and provide quality service.

Contents

I	Main technical data.....	8
II	User Instruction	10
III	Installation position of parts.....	12
IV	Ignition switch.....	14
V	Control system.....	16
VI	Essentials of driving.....	18
VII	Controls and setting.....	24
VIII	Inspection and maintenance.....	30

I - Main Technical Data

Mash Black Seven 125cc Euro 5

ENGINE	Engine Type	4T single cylinder, liquid cooled
	Engine Capacity	125 cc
	Compression Ratio	9.2: 1
	Idle speed	1500 ± 100RPM
	Power max	15 hp at 9000 rpm (11kW)
	Torque max.	9.5 Nm / 7500r / min
	Ignition	ECU
	Transmission	Chain
	Gearbox	6 speed
OTHERS	Spark plug	CR8E
	Battery	12V 9Ah
	Oil Engine	SAE10W-40
	Oil Engine quantity	950 ml
FRAME	Front tyre	90 / 90-17
	Rear Tyre	100 / 90-17
	Front Brake	disc Ø 300 mm, double piston caliper
	Rear Brake	disc Ø 210 mm, single piston caliper
	Brake	ABS
SIZE	Length /Width /Height	1970 x 720 x 1115 mm
	Saddle Height	760 mm
	Wheelbase	1340 mm
	Ground clearance	140 mm
	Weight in running order	137 kg
	Weight max	287 kg
	Fuel tank capacity	12 liters
CONSUMPTION	Speed max.	101 km / h
	Fuel	SP95 or SP98
	Consumption	2,1 L / 100 km
	Co2 emission index*	48 g / km
	Norme	EURO 5

This list is for information only. Modifications can be made by the manufacturer without notifying customers. Non-contractual photo.

**The fuel consumption values are taken under specific test conditions and are provided for comparison purposes only. They may not match the values in actual driving use.*



II - User Instruction

This user's manual describes the standard and safety method as well as basic maintenance. Read it carefully.

The images and illustrations in this manual may differ from those of your vehicle, if it is not the same model. The vehicle is designed for 2 people (driver included).

Caution

Do not use poor quality fuel.

Using poor quality fuel can cause deposits in the tank, which could block the fuel line and cause engine start-up failures or even serious engine damage.

Do not use inferior or poor quality motor oil. Always use a good quality engine oil to ensure engine performance and longevity. Any problem that appears due to the improper use of oil or gasoline cannot be covered by the warranty.

Protective Clothing

- Appropriate regulatory protective clothing, such as an approved helmet with a protective mask, approved gloves, high boots, must be worn while driving to ensure your personal safety.
- Loose clothing is not suitable for riding a motorcycle as it can get caught in the control levers, kickstarter, footrest or wheel.
- Always wear an approved helmet, approved gloves, high boots, a jacket.
- Drive carefully while always respecting the highway code
- Beware of the silencer which can be hot while driving.
- Always wear clothing that covers the whole body.
- **The above instructions are also intended for the passenger.**


Preparation before use

- Read the user manual carefully
- Maintain and check the vehicle before using it
- It is necessary to have the driving license corresponding to your vehicle and that it is insured
- Keep the engine off and away from any source of heat
- There are harmful substances such as carbon dioxide in the exhaust gases, always start the engine in a ventilated area
- Always wear an approved helmet, approved gloves, high boots, a jacket.
- Many traffic accidents between cars and motorcycles happen because the drivers do not see the bikers: always be vigilant!
- Make sure you are always visible to avoid accidents caused by others
- Wear bright or reflective clothing
- Always drive in the line of sight of other road users. Do not stay in the blind spot
 - Be particularly careful when approaching intersections. Always anticipate the reactions of other road users.

Caution

- **Not wearing a helmet increases the probability of fatal hurts in an accident**
- **Make sure the passenger always wears a full face helmet and protective clothing.**
- **Not to be in an abnormal state, anxious or excited. The driver's actions are very important for safe driving. Always sit in the middle of the saddle and especially not sit on the back of the saddle, this will lighten the weight in the front and cause the handles to shake.**
- **The passenger must hold the pilot and put his feet on the rear footrests.**
- **To turn, point your body to the side where you turn, otherwise it can be dangerous.**
 - **Driving on a winding and uneven road means that you absolutely must respect the safety instructions.**
 - **Driving on a winding and uneven road involves halving the speed, relaxing the shoulders and waist and squeezing the handles.**
 - **To drive, you must squeeze the handles with both hands, do not try to lift the front wheel, this facilitates overturning and causes serious accidents.**



III - Installation position of parts



Left side



Right side



1. Speed indicator :

Indicates the speed of the motorcycle (Km / h). Do not exceed the maximum authorized speed.

2. Turn signal indicator

⇒ (R) right, flashes when you turn right (green).

⇐ (L) left, flashes when you turn left (green).

3. High beam indicator lamp

When the head light is in high beam, the indicator is lit.

4. Tachometer: Indicates the engine speed (lap counter)

5. Fuel level indicator

6. Total or daily odometer.

Indicates the mileage of the trip, possibility of passing from the daily mileage (TRIP A and TRIP B) to the total mileage by pressing the button located below the meter

A long press on the day counter allows to reset the TRIP

A long press on the total counter allows you to switch from Miles to Kilometers and vice versa.

7. ABS Indicator

When the ABS system is activated, the light is off. It lights up in case of engine malfunction. If this light comes on, you should contact a dealer.

8. Engine light

If this indicator light comes on at the meter, it is necessary to go to an authorized Mash dealer to make a diagnosis.





9. Coolant temperature warning light

Illuminates orange when there is a warning

Illuminates red in case of an alarm - contact an authorized Mash dealer for diagnosis.

IV - Ignition switch.

The ignition switch controls the ignition and lighting circuits and allows the steering to be locked. Its various positions are described below.

Position	Fonction
	Position (OFF) All circuits are off: the key can therefore be removed.
	Position (ON) All electrical circuits are live: the engine can therefore be started. The key, however, cannot be removed.
	To lock the steering, turn the handlebars to the left, insert the key, push and turn it to the left until the steering lock logo
	To park the motorcycle with the sidelight on, turn the key to the « P » : » position: The handlebars are locked and the lights remain on: this makes it possible, at night, to signal the presence of the motorcycle parked at the side of the road



Headlights - Position indicator

Turn the main ignition key to position , the headlights come on automatically.




 **Caution**

*Do not change the position of the key while driving.
The engine and motorcycle must be stopped before removing the key.*



V - Control system

Left handlebar control system





Dimmer switch A

Press the button, using the switch allows you to choose the distance of the headlights : high or low.

-  High beam
-  Low beam


Turn signal switch B

Use the turn signals to turn left or right. Operate the button to the left or to the right, the indicator will flash. Press the switch again to stop the turn signal.

-  (R) Turn right
-  (L) Turn left

Caution

When you are finished turning, the turn signals do not turn off automatically. You have to press this button to stop them.



Horn Button C

Turn the key switch to the ON position, press the horn button and it will emit a sound.


Headlight flasher switch D

The flasher can be used to signal its presence.

Clutch grip E

Allows the motor to be disengaged in order to change gears.

Right handlebar control system



Electric starter button F


Press this button to start the engine.

Caution

Make sure that the vehicle is always in neutral position (N or 0) and always operate the clutch grip before starting the engine

Engine shutdown switch G

It is used to manually stop the motorcycle in an emergency situation.

Position it on  to be able to start the engine.

Front brake grip H

To apply the front brake, gradually press the brake grip located on the right handlebar. Since the motorcycle is equipped with hydraulic braking, the brake lever should not be manipulated either sharply or roughly. Pressing the lever automatically turns on the brake light.

Accelerator grip I

It makes it possible to vary the speed of rotation of the motor. The acceleration is done by making it turn towards you; deceleration, by releasing the handle.

Caution

Only use the emergency stop switch in an emergency situation.

VI - Essentials of driving



Fuel tank cap

To open the fuel tank cap, insert the key and turn it clockwise. The cap can then be removed with the key. To replace the cap, apply pressure on the cap and remove the key.

Fuel


Gas up

The fuel tank capacity is 12L. To fill your vehicle's fuel tank, put it on the main stand, open the fuel cap with the key and fill with fuel through the opening, then close the cap and remove the key.

- ① Fuel level
- ② Filling tube

⚠ Caution

The motorcycle is equipped with a fuel vapor recirculation system, do not overfill the tank.



⚠ Warning

Do not overfill the reservoir. Never spray fuel on a hot engine. Fill the tank to the lower level of the filler tube, otherwise fuel may overflow and expand with increased temperature.

Turn off the engine and turn the key to the OFF position when filling the tank. It is strictly forbidden to smoke or light a fire during this operation.

Starting the engine

Turn the key switch to the ON position. Make sure the emergency stop switch is in the ON position.


Make sure the gearbox is in neutral (N or 0) by checking that the neutral indicator light is on.

Make sure there is gasoline in the tank.

⚠ Caution

Make sure that the vehicle is always in neutral position (N or 0) and always operate the clutch lever before starting the engine

To start the engine

Make sure that the key switch and the emergency stop switch are in the «» position, that the gearbox is in neutral (neutral) and always operate the clutch grip.

To start, press the electric starter button. Never turn the throttle at the same time.

If the engine does not start, stop pressing the start button after 5 seconds and wait more than 5 seconds before restarting.

Twist the throttle slightly about 1/8 of a turn, but never more than 1/4 of a turn to increase the air intake and start the engine.

If the engine starts, but stalls while idling when it is cold, run the engine at a slight throttle, for 10 seconds or more, to warm it up.

Note: After starting the engine, immediately release the starter button to avoid damaging the engine.

⚠ Warning

Get in the habit of engaging neutral and pressing down firmly on the clutch lever before starting the engine: this helps prevent being thrown forward if the wrong gear is engaged.

Never start the engine in a poorly ventilated or poorly ventilated room: carbon monoxide emissions are indeed toxic. Never leave the motorcycle with the engine running unattended.

⚠ Caution

Do not let the engine run for an extended period without driving: the overheating which could result will damage the mechanical parts and the chrome coating of the exhaust.

Gear change

1. When stopped, with the engine at idle speed, disengage and press the selector with your left foot to shift from neutral to first.
2. When the motorcycle stabilizes, bring the throttle back and disengage the clutch again, then raise the selector to go into second.
3. Proceed in the same way to go from the 3rd, 4th, 5th & 6th

⚠ Caution


Do not depress the gear selector instead of raising it while driving, you risk downshifting and causing the engine to over-speed.

Downshift

If you want to accelerate sharply, for example to overtake, downshifting can cause faster acceleration, but if the rpm gets too high it can damage the engine.

At high speeds, downshifting can cause the engine to over-rev. Before engaging a lower gear, it is necessary to slow down to avoid any engine damage.

Up reports



Down reports



⚠ Caution

When you shift into neutral, the neutral indicator light (N or 0) comes on on the instrument cluster (if equipped). Even if the light is on, gradually release the clutch lever to make sure the transmission is in neutral.

Functioning

- Before starting the engine, make sure that the sidestand is fully folded up.
- If you cannot easily move the sidestand, check that the kickstand is lubricated.
- Change gear appropriately in relation to engine speed.
- To consume little fuel and ensure the longevity of your machine, do not drive at high speed and favor low and medium speeds.

Break-in

Running 1000 km of break-in at a speed not exceeding 6000 rpm will improve engine life.

⚠ Caution

- *Always start the vehicle first and start as gently and carefully as possible.*
- *If you hear any abnormal noise while driving, contact a MASH dealer to have it checked.*
- *Never exceed the authorized speed.*

Brake

- Use the front brake and the rear brake simultaneously.
- Avoid braking suddenly if it is not necessary.

⚠ Caution

- *If you only use the front or rear brake, the motorcycle could slip.*
- *If you are riding in rainy weather or on a wet road, braking suddenly can cause accidents, adjust your speed according to the conditions and use the brakes appropriately.*
- *Braking repeatedly causes the brakes to overheat and reduce their effectiveness.*

Engine brake

The motor can act as a brake during deceleration. If you want to brake harder, we suggest you downshift, being careful not to over speed the engine. However, if you need to bring the motorcycle to a quick stop, you can use the brake and engine brake at the same time.

⚠ Caution

When the motorcycle is being driven at high speed, do not downshift immediately, it may suddenly reduce the speed and damage the engine and transmission system, and even block the rear wheel of the vehicle.

Parking

- Position the gearbox in neutral (N or 0) and turn off the engine.
- Use the side stand to keep the motorcycle stable and park it on level ground, otherwise it will fall. The vehicle is fitted with a side stand. To immobilize the vehicle using the side stand: press the end of it with your foot to fully unfold it.

⚠ Caution

- *Park the motorcycle in a safe place where there is no traffic.*
- *Always park the motorcycle on a level and stable surface.*
- *The silencer can be very hot, do not park your motorcycle in a place where there are traffic, there is a risk of burns.*
- *If you park the motorcycle on a slope, stop it uphill to prevent it from descending.*
- *To drive in complete safety, check before resuming the road that the stand side is fully raised and remains perfectly in place.*

Parking and using the steering lock

Place the motorcycle on level ground and put on the side stand.

Then turn the handlebars to the stop on the left side and position the key switch in the steering lock position (padlock logo).

Remove the key from the switch, the handlebars are now locked in the parking position.

⚠ Caution

- *If the handlebars are turned to the right or if the motorcycle's side stand is incorrectly positioned, the vehicle may fall.*
- *In unavoidable situations, adequate measures must be taken to ensure stability.*

Mirrors

Before driving, always adjust your mirrors.

⚠ Warning

Do not put anything in the rear seat so as not to obstruct visibility in the mirrors.

Do not adjust your mirrors while driving.

⚠ Caution

To clean your mirrors, use a soft cloth. Use a suitable cleaning product without putting it directly in contact with the mirrors.

Rear shock absorbers


Absorbers adjustment

Rear wheel shock absorbers can be adjusted to suit the load, riding style and road conditions.

Place the vehicle on its side stand and turn the absorbers adjustment ring to the desired position. The first position is the most flexible, the fifth the hardest.

⚠ Warning

Always carry out the same adjustment on the 2 shock absorbers. It is important to carry out the operation for both absorbers simultaneously, at the risk of distorting the handling of the machine.



Tool kit

The tool kit is located below the right side fairing. To grab the kit, remove the side cover.



VII - Controls and setting

Running-in

The importance of a good running-in of the new vehicle has been stressed in the Foreword and presupposes compliance with the rules set out below.

Maximum speed

The maximum speed during the various running-in stages is given in the following table.

During the first 1000 kilometers, the throttle grip should be turned to a maximum of 70%.

Change of engine speed

Do not ride for too long at a constant speed. Vary the engine speed to complete the running-in. It is essential to change speed from time to time so that the moving parts of the engine undergo different stresses which will guarantee their correct adjustment: in fact, when the pressure exerted on them falls, they cool down and acquire the desired position. For the same reason, it is also strongly recommended to practice gentle revs during running-in, while taking care not to subject the engine to excessive stress.

Avoid driving too low or too high

Driving at low revs for long periods of time can cause engine and transmission jerkiness. The owner of the motorcycle is therefore encouraged to ride at the most varied speeds while refraining from accelerating too sharply and from cranking the engine to very high revs. However, it is strongly recommended not to accelerate fully during the first 1000 kilometers.

Let the oil circulate before riding

After starting the engine (hot and cold) and before setting off, let the engine idle for a period of time suitable for it to warm up properly. This allows the oil to spread over every part of the engine and do its part in reducing wear and improving its life, while bringing the engine to a suitable operating temperature.

First maintenance check

Maintenance is of critical importance during the first 1,000 kilometers. During the running-in, the engine parts, but also those of other parts of the vehicle, adjust gradually: once the break-in is complete, it is therefore necessary to check all the tightening and replace the old engine oil. and the oil filter.

Carrying out a maintenance check after the first 1000 kilometers helps to ensure engine longevity and best performance.

Lubricant

By using a high quality lubricant suitable for a four stroke engine, you will extend the life of your engine. Please select the type of high quality IPONE SAE10W40 lubricant.

Engine oil

Replacing the engine oil.

Engine oil plays an important role in the normal operation of the engine and for this reason it is necessary to check the engine oil periodically and to renew it after the first 1000 km and then every 5000 km according to the procedures. following.

Note : When draining, clean the gauge (if equipped) and replace the oil filter.

Engine oil change

Replacing the engine oil should be done while the engine is still warm to allow the fluid to drain completely.

To do this, proceed as follows:

1. Immobilize the motorcycle by placing it in a vertical position
2. Remove the oil filler cap
3. Unscrew the drain screw and let out the used oil
4. Replace the oil filter

⚠ Caution

Check carefully for leaks around the oil filter cover.

5. Tighten the drain screw and fill with new oil

The total engine oil capacity is 950mL (engine dismantling)

Drain screw tightening torque: 20-30 Nm

6. Check the oil level using the gauge (if equipped) or the oil level sight glass.

Checking the oil level

Before each use of the vehicle, always check the oil level with the gauge or the oil level sight glass to make sure that the amount of oil is correct.

⚠ Caution


The use of inferior quality oil can permanently damage the engine and seriously shorten its life.

Coolant



Caution
This engine has a liquid cooling system. During the operation of the motorcycle, the coolant is at high temperature and high pressure in the cooling system. Therefore, it is strictly forbidden to open the radiator cap in this condition, in order to prevent and avoid burns.
The coolant must be added in time and in sufficient quantity to avoid damage to the engine.
Coolant should be added after the engine has stopped and cooled down.
Antifreeze belongs to the chemicals, which include toxic substances. If the antifreeze gets into the eyes or on the skin, wash immediately with plenty of water.

Coolant tank



On the right side of the front end of the vehicle’s fuel tank is equipped with a coolant make-up tank ① and the radiator cap ②. The coolant top-up tank ① is equipped with level graduations in the tank, the level should be between upper and lower graduations. When the water level is below the minimum limit, open the radiator cap ②, add special antifreeze to the makeup tank, do not add tap water or other liquid

Pre-ride inspection

Before road, remember to check the following points. Never underestimate the importance of inspection.

Element	Control to be carried out
Handlebar	Ensure that direction is: - soft - free - no hard point in rotation
Lighting	Operate all lights (front light, rear light, front and rear brake light, instrument cluster lighting, turn signals)
Engine oil	Check the oil level

Brakes	- Adjust the «play free» of the rear brake pedal and the front brake lever - Ensure effective braking - Check for leaks
Indicator lights	Engine light, gear engaged, oil level, turn signals, high beam
Accelerator grip	- Check the tension of the accelerator cable - Check that there is no hard point or resistance in the rotation of the handle and that it returns to the initial position.
Tires	Check the tire pressure Check the depth of the tread patterns (wear) Check for nicks or cracks
Audible warning device (horn)	Ensure proper operation
Clutch	Check the tension of the clutch cable. Check its proper functioning and the effectiveness of the clutch
Fuel	Fill the tank with the correct fuel. Do not overfill the reservoir.
Transmission	Check the tension. Check lubrication
Coolant	Check coolant level Check for leaks

Rules of conduct



Warning
If this is your first time riding this type of motorcycle, we recommend that you familiarize yourself with its controls and operation on a low-traffic road until you have mastered it.
Before setting off, check that the sidestand is correctly raised.
Do not accelerate sharply or downshift in a turn or change of direction.
Slow down enough when braking before entering a turn.
It is dangerous to operate a motorcycle with one hand. When riding, always hold the handlebars firmly with both hands and keep your feet on the footrests. Never take both hands off the handlebars at the same time.
On wet roads, the friction force being low, the braking distance increases and it is more difficult to change direction: so remember to decelerate in advance.
Always respect traffic rules and speed limits

First turns of the wheel with the motorcycle

Caution

Start the engine with the transmission in neutral, the clutch engaged and the rider in the normal driving position.

Pass a gear report

Press down firmly on the clutch grip, wait a brief moment, lower the selector to engage first gear, gently turn the throttle toward you and slowly and smoothly release the clutch lever. The motorcycle begins to move when the clutch is gradually released.

To upshift, first accelerate slightly, then, releasing the throttle, pull the clutch lever, move the selector up with your left foot and release the clutch lever, before accelerating. again. Proceed in the same way until the maximum gear.

Downshift to slow down

Before downshifting, it is necessary to start reducing speed by braking. As soon as the engine speed is sufficiently reduced, you can pull your clutch lever and then with your left foot depress the gear selector in order to downshift a gear. Then release your clutch lever gradually to use the lower gear engine brake.

Proceed in the same way until the minimum ratio.

Warning

Never downshift 2 gears at the same time, you risk damaging the engine if you over-speed.

Never release the clutch grip abruptly, as this may jerk or block the rear wheel momentarily.

Driving on a down hill

On a descent, you can pick up more speed than normal without accelerating. Use engine braking to stabilize your speed and brake to slow down when needed.

Before downshifting, slow down enough to avoid a sudden increase in engine speed, which could damage the transmission, increase wear on parts, and even unbalance the motorcycle while riding.

Warning

Remember never to go down a hill at too high a speed!

Driving uphill

When going up a steep hill, the motorcycle may decelerate. In this case, downshift immediately to bring the engine speed within the normal operating range. Be sure to change gear quickly to maintain its pace.

Warning

Never put excessive stress on the engine for an extended period of time.

Braking

Riders with little experience are usually content to use only the rear brake, which causes premature brake wear and increases the stopping distance. In addition, this would promote locking of the rear wheel and loss of control of the vehicle.

Therefore, it is strongly recommended that you do not use only one of the two brakes.

On wet roads or any other smooth surface, use extreme caution in gradually applying the brakes simultaneously. Abrupt braking on slippery, bumpy or smooth road surfaces is extremely dangerous. Always anticipate your braking in advance.

Warning

The greater the braking distance the faster the vehicle speed is. Be sure to correctly assess the distance to the vehicle or object in front of you to brake accordingly.

VIII - Inspection and maintenance

The following table specifies the periodic maintenance intervals expressed in distance traveled or number of months. At the end of each period, remember to perform the inspection, lubrication and maintenance. If the motorcycle is routinely operated at a high load (for example, heavy engine load in dusty areas), perform maintenance at regular intervals. Your dealer will give you additional maintenance advice. The components of the steering, shocks, bearings and wheels are essential to the operation of the vehicle and should only be maintained and repaired by qualified professionals. To ensure your safety, it is recommended that inspection and maintenance be performed by your authorized MASH dealer.

⚠ Caution
*During periodic maintenance, it may be necessary to change one or more parts: these must be replaced by original parts. Regardless of your vehicle maintenance experience, items marked with the * symbol should be supported by your dealer and qualified service personnel. You can perform maintenance on items not marked with this symbol, provided you follow the instructions.*

⚠ Warning
Once the vehicle has been broken in, maintenance is mandatory to ensure its safety and to fully exploit its performance.

Perform periodic maintenance in strict accordance with the instructions given in this manual.

Please note that the service interval is 5000 kms. Do not forget to certify them in the maintenance sheets of the warranty booklet provided by your MASH dealer.

PERIODIC MAINTENANCE CHART

Interval: According to the first deadline in Kilometers or number of months.	KM	1000	5000	10 000	15 000
	Number of months	6	12	24	36
Battery		I	I	I	I
* Spark plug		I	N	R	N
* Clutch		I	I	I	I
* Air filter		I	N	R	N
* Fuel filter		R	I	R	I
* Fuel hoses		I	I	I	I
		To be replaced every 4 years			
* Engine oil and oil filter	12 months or 5000 km	1st revision	R	R	R
* Oil filter strainer		N	N	N	N
* Valve clearance		I	I	I	I
* Timing chain		I	I	I	I
* Chassis bolts and nuts		S	S	S	S
* Brakes, front and rear brake pads, linings		I	I	I	I
* Brake fluid		I	I	I	I
		Replace every 2 years or 20,000 km			
* Brake hoses		I	I	I	I
		To be replaced every 4 years			
Brake contactor		I	I	I	I
* Suspension system (operation, condition...)		I	I	I	I
Wheels and tires		I	I	I	I
Transmission chain		I	I	I	I
		Clean and lubricate every 1000 kms			
* Steering, bearings		I	I	I	I
* Coolant		I	I	I	I
		Replace every 2 years or 20,000 km			

Legend:

I: Carry out an inspection, cleaning, adjustment, tightening, lubrication or replacement.

N: Cleaning.

R: Replacement.

S: Tightening

* This item should be serviced by a MASH dealer

LUBRICATION CHART

Interval	Every 3,000 km or 12 months	Every 6,000 km or 24 months
Element		
Throttle grip cable	Engine oil or (1)	Engine oil or (1)
Clutch cable	Engine oil or (1)	Engine oil or (1)
Tachometer cable	-	Grease (2)
Transmission channel	Lubricate every 1000 km (3)	
Axle, brake caliper piston	-	Grease (2)
Throttle grip	-	Grease (2)
Brake cable	Engine oil or (1)	Engine oil or (1)
Tachometer gearbox and wheel bearings	-	Grease (2)
Brake pedal, various axles, pivots	Grease or (1) (2)	Grease or (1) (2)
*Direction	To be lubricated every two years or every 6000 kms	

Reference IPONE : (1) Full Protect / (2) Waterproof Grease / (3) X-Trem Chain Road


Outillage

To facilitate regular maintenance of the motorcycle, a set of tools is available in the kit placed with the vehicle.

Battery

The battery is normally placed under the right rear fairing of the vehicle. Two models are available for this model: maintenance free or SLA (factory activated).


Respect the polarity of the battery by connecting the red wire to the positive (+) terminal and the black wire to the negative (-) terminal. Improper connection will damage the charging system and the battery.
Note : After the first 1000 km, then every 3000 km or every 6 months, have the capacity of your battery checked by your dealer.

 **Caution**
Never damage, block or change the battery breather hose. Make sure that the breather hose is connected to the corresponding port on the battery and that its other end is not blocked or pinched. The breather hose and the battery must be installed correctly.

Spark plug

After driving the first 1000 km, then every 5000 km, clean the carbon deposits from the spark plug using a small wire brush or spark plug cleaner. Using a feeler gauge, adjust the gap between the electrodes, keeping a value between 0.6 and 0.8 mm. Replace the spark plug every 10000 km.

The carbon deposits having been removed, observe the color of the candle to see if it is suitable for its use. A wet or very dark standard candle means poor combustion with an overly rich mixture. A light gray or cotton yellow colored spark plug indicates good combustion and normal conditions of use. An extremely white spark plug, on the other hand, reflects poor combustion and overheating of the engine.



⚠ Caution

Do not overtighten the spark plug to avoid damaging the cylinder head threads. When removing it, prevent dirt from falling into the engine through the spark plug hole.


The original spark plug fitted to the motorcycle has been carefully selected to suit various operating conditions. If the color of the candle does not comply with normal conditions of use, we recommend that you contact your dealer.

As the choice of an unsuitable spark plug (for example from another manufacturer) is likely to seriously damage the engine, we therefore invite you to contact your dealer before choosing a product sold under another brand.

Engine oil

The longevity of the engine depends on the quality of the oil used, the frequency of its replacement and the checking of the oil level.

Checking the engine oil level



1 **Filler cap**

2 **Oil level eyecup**
F : Maximum level
L : Minimum level

⚠ Caution

The oil level eyecup markings (2) indicate the oil level. If this is below the minimum level (L), never start the engine. Add oil until the level reaches the top mark on the oil level eyecup (F)

Changing the engine oil and the oil filter

Change the engine oil and strainer after the first 1,000 km, then every 5,000 km. The change must take place when the engine is still hot, in order to allow a complete draining of the hot fluid. To do this, proceed as follows:

1. Secure the motorcycle by placing it in an upright position.
2. Remove the oil filler cap.
3. Remove the drain plug from the strainer cover (below the engine) to drain.



4. Tighten the drain screw and fill the oil tank with the necessary amount of oil, before gently tightening the top plug.

Note : Always check the oil level to make sure the amount of oil is correct.

5. Start the engine and let it idle for a while.

⚠ Caution

Check carefully for leaks around the oil filter cover.

6. Stop the engine and wait about a minute before checking the fluid level with the dipstick. The level must reach the "F" mark (for full). If the level is below the «F» mark, top it up.

⚠ Caution

Preferably use Ipone R4000 RS 10W40 engine oil

Brakes

ABS :

Your motorcycle is equipped with a system that limits front wheel locking during periods of heavy braking (ABS).

If the ABS indicator light comes on, you should go to an authorized Mash dealer for a precise diagnosis.

The front brake is equipped with a disc. Check the brakes after the first 1000 km, then every 5000 km. Proper operation of the brakes is critical to safe riding. Have the brake system inspected periodically by your authorized dealer.

Warning

The efficiency of the braking system is essential for the safety of the user and must be guaranteed at all times. Repair of the brake system or replacement of the brake linings should preferably be carried out by your dealer. Your dealer has the necessary tools and proven techniques to carry out these operations in a safe and economical way.

Front brake

If the motorcycle is equipped with a front disc brake, the brake lever clearance must be between 5 and 10 mm (measured at the level of the dome).

The hydraulic brake system should be checked daily, as follows:

- 1) Check the front wheel brake system for leaks.
- 2) Check the brake hose for leaks.
- 3) Check that the front brake lever offers some resistance when it is actuated.
- 4) Check the front wheel brake linings for wear.



Caution

Disc brakes are part of a high-pressure system. For your safety, the hydraulic oil replacement interval should not exceed the interval specified in the periodic maintenance chart in the manual.

Brake fluid

Warning

Brake fluid is poisonous. If accidentally swallowed, spit it out vigorously. In case of contact with the skin or the eyes, rinse thoroughly with clean water and seek immediate medical attention.

Check the brake fluid level in the front brake master cylinder reservoir, remembering to top it up if the level is too low. Apart from the wear of the linings, the decrease in the level in the reservoir can also be explained by the existence of leaks in the brake hose. Filling the tank is an important part of the periodic maintenance of the vehicle.

Caution

The vehicle runs on hydraulic oil. Mixing with silicate or petroleum-based fluid is prohibited, as this will seriously damage the braking system. Never use brake fluid from an already opened container or from a surplus stored since the last service: the fluid may have absorbed moisture. Only DOT4 brake fluid should be used. Be careful not to splash hydraulic oil on the paint or plastic surfaces to avoid any risk of corrosion.

Ipone reference: brake dot 4

Brake pads

Checking the pad linings is essentially limited to checking their state of wear by comparing their thickness with the groove forming a mark. The pads should be replaced if they are worn to the bottom of the groove.

Warning

Do not drive immediately after changing the pads. Depress the brake lever several times to position the pads against the rotor.

Front brake light switch

The front brake light switch is located below the brake lever. Unscrew the screw, then move the switch, if necessary in one direction and then in the other, until the fire comes on at the slightest pressure on the brake.



Rear brake light switch

The rear brake light switch is located on the right side of the motorcycle. Raise or lower the switch so that the light comes on at the slightest pressure on the brake pedal.

Rear Brake

Adjusting the rear wheel brake

The rear brake is a disc brake. To adjust the rear wheel brake pedal, move the pedal to the most comfortable driving position by turning the lock nut (1). Once the position has been adjusted, lock it with the lock nut (2). Please keep the clearance between 10 and 20 mm (3).



Check the condition of the brake pads regularly. The thickness of the lining must be greater than 2 mm. If the lining thickness is less than 2 mm, the brake pads must be replaced.



Degrease the rear brake disc at regular intervals to ensure optimum braking quality at all times.

In case of brake fluid leakage, contact your MASH dealer.

In case of braking problems, contact your MASH dealer.

Brake fluid type: DOT4

In case of brake problems, please contact your MASH dealer.

Exhaust pipe


It is advisable to keep away from the exhaust pipe after a long journey to avoid any risk of burns.



Air filter

Clogging of the air filter due to the accumulation of dust can reduce engine power and increase intake resistance, thus increasing fuel consumption. It is therefore important to check its condition and clean it regularly. To do this, observe the following procedure:


1. Remove the left side fairing.
2. Unscrew the outer screws of the air filter cover (1) and remove the air filter sleeve (2).
3. Remove the air box cover in which the air filter foam is located.
4. Separate the foam from the air box cover.



⚠ Caution

- If the motorcycle is used in dusty areas, check and clean the air filter at shorter intervals than those prescribed in the maintenance table.
- When cleaning the filter, check that it is not damaged; if necessary replace it.
- Never start the engine without first replacing the air filter: this could aggravate engine wear.

Clean the foam filter as follows:



1. Fill a suitable size container with a non-combustible cleaning solution. Submerge the foam in the cleaning solution, then rinse it.
2. Squeeze the foam between the palms of the hands to remove the cleaning solution. Never twist the filter as this may damage it.
3. Dip the filter in the engine oil tank, then wring it out to remove the oil: the foam should be slightly damp.
IPONE reference: AIR FILTER CLEANER / AIR FILTER OIL
4. Replace the filter in reverse order. Make sure that the filter is correctly replaced and perfectly protected.

⚠ Caution

- **Before and during cleaning, make sure that the filter is intact; if it shows any damage, replace it.**
- **Cleaning and replacing the air filter should be done more frequently if the vehicle is used in dusty areas.**
- Never start the engine without first replacing the air filter: this could aggravate engine wear.**
- The effectiveness of the air filter partly conditions the longevity of the engine, so it is essential to check its condition.**

Injection

Your Mash motorcycle is equipped with an injection system (EFI) to optimize the air / fuel mixture. Prohibition and inability to adjust the injection system. Therefore, it is not possible and strictly forbidden to adjust the motorcycle's injection system. If the EFI warning light on the meter comes on, you must go to an authorized Mash dealer in order to carry out a diagnosis.

Adjusting the play of the throttle cable



1. Lock not 2. Adjusting nut


1. Loosen the lock nut.
2. Turn the nut so that the cable play is between 0.5 and 1.0 mm.
3. After adjustment, retighten the locknut.

⚠ Caution



When the throttle cable free play has been adjusted, check the throttle grip for proper operation. The setting will have no effect on the engine idle speed, and the handle will automatically return to the closed position.

Clutch adjustment (guard)

Clutch adjustment is made by adjusting the tension of the clutch cable. Before disengaging by pulling the clutch lever, the cable play measured at the clutch lever should normally be 10 mm. If the measured value is different, adjust as follows.




Loosen the nut (1) and turn the tension ring of the lever (2) fully clockwise. Unscrew the lock nut of the cable tension ring (5), before turning the ring (4) in one direction and then in the other until the play of the lever reaches approximately 4 mm. The lever adjustment ring (2) can optionally be used to fine-tune the adjustment. Once the adjustment has been made, retighten the locknut (1) and the ring (5), then wrap them with the rubber sleeve (3).




Adjusting the transmission chain

To adjust:

1. Secure the motorcycle on its side stand or center stand (if equipped).
2. Loosen the nut on the rear wheel axle.
3. Loosen the lock nut.
4. Turn the adjustment bolt left or right to achieve the desired adjustment.



1. Adjustment bolt
2. Lock nut
3. Alignment mark
4. Rear wheel axle nut




Note: When installing a new chain, it is necessary to check the pinion and crown. It is advisable to replace the chain kit.

The tension of the drive chain should be adjusted every 1000 km so that the play is between 20 and 30 mm.

⚠ Caution

The closed (rounded) part of the chain quick release clip should face the direction of chain rotation.

1. Quick chain clip
2. Direction of rotation



Cleaning and lubricating the drive chain

The accumulation of dirt on the drive chain can worsen its wear and that of the sprockets. It is therefore strongly recommended to clean the chain every 1000 km using a cleaning solvent, then grease it with a special lubricant or engine oil.


Reference: IPONE: Chain Cleaner / X-TREM Chain Road.

Tires

Check the tire pressure and their tread after the first 1000 km, then every 3000 km. In addition to periodic checks, get in the habit of checking tire pressure from time to time to prolong tire life and ensure maximum safety.

Tire pressure


Insufficient pressure can worsen tire wear and affect vehicle stability: in particular, changes of direction can be more difficult. Conversely, excessive pressure, by reducing the contact surface between the tires and the road, increases the risk of skidding or even loss of control of the vehicle. Therefore, it is necessary for the tire pressure to remain within the specified limits. The tire pressure should be adjusted when cold, before driving.



Black Seven 125cc pressure: Front - 2 bar / Rear - 2.3 bar

Tread Sculptures

Riding a motorcycle with worn tires compromises its stability and comes with an increased risk of loss of control. If the tread depth of the front wheel is not sufficient, it is advisable to have the tire replaced. This operation is also necessary for the rear tire if the depth of the rear wheel tread is not sufficient.



⚠ Warning

As the use of tires other than the standard models can cause problems, it is strongly recommended that you use tires identical to the original ones. Compliance with the recommended tire inflation pressure is essential, it directly determines the performance of the vehicle and driving safety. Check tire wear and pressure from time to time.

Repair


If the engine cannot be started, examine each of the following for the cause of the problem.

1. Check if the tank is full of fuel.
2. Check that the battery is properly charged.
3. Check that the circuit breaker (on the right stalk) is not activated.
4. Check that the starter motor operates when you operate the handlebar starter button.
5. If so, go to the next step to check the ignition system.



Warning
Never let the fuel run out. Collect it in a container. Move it away from the hot engine and the exhaust pipe. During operation, keep away from any flame or heat source.

Smoking is strictly prohibited when checking the fuel system. Carry out the operation in a place large enough to be comfortable

1. Remove the spark plug and connect it to its high voltage cable
2. Turn the ignition key to the ON position, the engine circuit breaker to the «  » position. Place the spark plug near the engine, and start it. If the ignition device is functioning properly, blue sparks will fly between the electrodes of the spark plug; otherwise, call your dealer for repair.



Warning
Do not carry out the above operation by fixing the spark plug near the tank or any inflammable source, otherwise a fire will be caused by the combustion of the fuel vaporized in the cylinder.

To avoid electric shock, it is recommended that the metallic part of the spark plug be contacted with the metallic part of the motorcycle engine. People with heart disease are prohibited from performing this operation.

Engine shutdown

1. Check the fuel level in the tank.
2. Check the condition of the spark plug.
3. Check the operation of the motor with no load.

Note : *It is advisable to consult your dealer beforehand before any repair operation. If the warranty has not yet expired, contact your dealer immediately before carrying out any repairs yourself. Any unauthorized manipulation during the warranty period will invalidate the services provided by the latter. (Refer to the warranty booklet provided by the authorized MASH dealer.)*

Fault diagnosis table

Problems		Causes	Solutions
The engine does not start or stalls	Normal ignition in the high voltage cable, no ignition in the spark plug	<ul style="list-style-type: none"> • Oil fouling of the spark plug • Breakage of the magnetic core of the spark plug or of an electrode (s) • Presence of carbonaceous deposits on the spark plug electrodes • Incorrect spacing of the spark plug electrodes 	<ul style="list-style-type: none"> • Extract, clean and dry the candle • Replace the spark plug • Eliminate carbonaceous deposits • Adjust the spacing
	Normal ignition in the spark plug, insufficient cylinder compression	<ul style="list-style-type: none"> • Leaking cylinder head gasket • Ignition plug tightening fault • Excessive wear of the piston or breakage of one or more piston rings • Leakage from the intake duct 	<ul style="list-style-type: none"> • Tighten the screw or replace the gasket • Tighten the spark plug • Replace the piston or some of its segments • Tighten or replace the rubber part
Engine malfunction	Abnormal engine noise	<ul style="list-style-type: none"> • Premature ignition • Excessive accumulation of carbonaceous deposits in the combustion chamber • Overheating of the spark plug 	<ul style="list-style-type: none"> • Replace bearings and auxiliary parts • Adjust the ignition time • Eliminate carbonaceous deposits • Replace the spark plug
	Engine running instability	<ul style="list-style-type: none"> • Fouling of the fuel intake circuit • Leak at the crankcase 	<ul style="list-style-type: none"> • Clean or replace the fuel inlet pipe • Replace the gasket
	Engine overheating	<ul style="list-style-type: none"> • Prolonged driving at low revs • Driving (prolonged or not) overloaded • Use of non-recommended engine oil or insufficient oil level • Clutch slippage • Excessive chain tension • Brake release fault 	<ul style="list-style-type: none"> • Change gear and control the duration • Check the load and stop from time to time to let the engine cool down • Replace the fluid with the recommended engine oil, filling up to the mark • Adjust the stroke or replace the clutch, friction linings and spring • Adjust the tension • Adjust the brake lever play

In the event of a breakdown, for an accurate diagnosis, contact an authorized MASH dealer.

Storage and cleaning

Prolonged non-use of the motorcycle during winter or another season requires specific operations requiring suitable materials, equipment and techniques.

Motorcycle

If the motorcycle will not be used for an extended period of time, perform the following operations before storing it: Wash the motorcycle and stabilize it with its side stand on hard, level ground. Rotate the handlebars to the left and lock the steering. Remove the ignition key. Choose a location suitable for long-term storage for the safety of the two-wheeler. Before reusing it, carry out a complete inspection to verify the performance of all parts.

Fuel

Before immobilizing the motorcycle, empty the fuel tank: gasoline is indeed highly flammable, and can even become explosive under certain conditions. Never leave the motorcycle near a heat source. Never park it in a place where there are very flammable materials (grain, coal, cotton, etc.): the fuel in the tank could start a fire by coming into contact with the flames.

Tires

Inflate the tires to normal pressure. Keep their surface clean. Avoid prolonged exposure to direct sunlight or moisture. Avoid contacting the tires with corrosive solutions (acids, alkalis and oil).

Battery

In case of prolonged non-use, remove the battery and fully charge it before storing it in a safe place out of the reach of children. Then recharge it once a month in summer, once every two months in winter. If the battery is left in place for a long time, recharge it once a month.

Storage and its stages

If the motorcycle is equipped with a conventional battery, check the electrolyte level once a month. If the fluid level is low, quickly add distilled water to the upper mark. (Never use electrolyte or tap water)

Keep the battery clean at all times. There is a risk of corrosion in the event of electrolyte splashing on the vehicle body or on the battery terminals and wires. If this happens, rinse immediately with clean water and apply a layer of grease after drying.

A lack of power can cause difficulty starting, reduce the sound level of the horn and prevent the turn signals from functioning. Recharge the battery immediately for 15 to 20 hours. Note that prolonged storage of a discharged battery may damage it.

A battery has reached its maximum operating time if: its terminals are covered with a white deposit; it delivers low power; the electrolyte volume is less than the minimum mark and, in each of the above cases, if its performance cannot be restored after long-term storage, even after recharging.

Reuse after storage: the procedure

1. Thoroughly clean the motorcycle.

2. Remove the spark plug; press the starter to let the engine run for a few moments before reinstalling the spark plug.

3. Replace the battery. Note: Do not forget to connect the positive pole before the negative pole.

4. Inflate the tires to the pressure specified in the corresponding section of this manual.

5. Lubricate all the parts requiring it by proceeding as indicated in this manual.

6. Observe the instructions in “Pre-ride inspection” before setting off.

Cleaning

Frequent and regular cleaning is an essential part of maintaining your motorcycle. Exposure to natural elements (sea breeze, sea water, mud, dust, etc.) and to non-slip additives spread on the roads in winter, can be a source of vulnerability for the components of your motorcycle. Corrosion and rust can appear even on good quality parts. Proper maintenance and regular cleaning of your vehicle will not only prolong its original appearance, but also are essential in order to maintain warranty rights.

Precautions Before Cleaning

When the engine is cold, protect the exhaust outlet with suitable protection (example: plastic bag) to prevent water from entering inside.

Exposed electrical components should be covered with a plastic bag. Check that the lids and caps are correctly positioned.

Using a degreaser and a soft brush, remove any major stains that may be on the crankcase, making sure never to apply it to the gears, transmission chain, seals and wheel axles. . Rinsing of residues and degreaser will be done with water.

Cleaning :

Cleaners that are too acidic or aggressive are not recommended for washing the motorcycle. Particularly at the level of axles, bearings, levers, pivots, wheels and spokes. If, however, it is necessary to use it for stubborn stains, follow the instructions and application times for the product. We recommend that you spray these parts with an anti-corrosion product after rinsing with plenty of water.

Plastic parts and windshields (for equipped vehicles) should preferably be cleaned with water using a sponge or soft cloth. Only a mild detergent can be used if some plastic parts cannot be cleaned properly. Rinse the product used abundantly: poorly rinsed, it could damage the plastic parts. The use of all other products on plastic parts is strictly discouraged (thinner, solvent, gasoline, antifreeze, abrasive cleaner, etc.).

⚠ Caution

Special precautions: Do not use a high pressure cleaner or steam jet: Avoid directing the water jet near the following items: on-board instruments, brake cylinders and calipers, under the fuel tank, transmission chain, bearings steering column, gaskets, air box, wheel or swingarm bearings, all electrical components as well as air vents. Water infiltration could damage these elements.

After use under normal conditions:

Soak in lukewarm water mixed with a mild detergent using a soft sponge, then rinse thoroughly. A damp cloth placed for a few minutes on parts with more stubborn stains and insects, will loosen dirt gently.

After use in the rain, near the sea or on salty roads:

Clean the motorcycle with cold water and a mild detergent: do not use hot water, this will increase the corrosive action of the salt. Protect the vehicle from corrosion by spraying an anti-corrosion product on all metallic, chrome or nickel-plated surfaces.

After cleaning:

Dry body parts with a chamois leather or soft absorbent paper. After being dried with a disposable disposable cloth, the transmission chain should be lubricated with a specific lubricant to prevent it from rusting. It is advisable to scrub chrome or stainless steel parts (including the exhaust system) with a chrome cleaner. An anti-corrosion product should be sprayed on all metallic, chrome or nickel-plated surfaces. Lubricate the pivot pins, bolts and nuts. Apply wax to all painted parts.

⚠ Caution

Special precautions: Never use lubricating or greasy products on the braking elements. This could decrease braking efficiency and cause an accident.

Always use a specific degreaser for braking systems.

Copyright in this manual and its ultimate interpretation is ours. Under no circumstances may this document or any part of it be reproduced or cited without our prior written permission.

All information, descriptions, illustrations and specifications contained herein reflect the state of our knowledge at the time of publication. However, we reserve the right to modify this manual at any time in the event of improvements or other changes.

Product specifications and parameters are also subject to change without notice!

Product configuration and availability of spare parts may vary by country or region. For more information on this, please consult your local distributor!

**Local distributor :
MOTOMONDO
Lorentzlaan 14,
3401 MX IJsselstein
NETHERLANDS**



www.motomondo.com

Find your reseller



JOIN US ON SOCIAL NETWORKS:



@mashmotors_benelux & mashmotors_uk



@mashmotorsbenelux & mash.motors.uk



@mash motors west europe



MotoMondo